



INSTRUCTIONS:

TO ATTACH THE HOOKS TAKE OUT THEM OF THE SLIDE DOOR, ALING UP THE HOOKS ON TOP (AS SHOWING FIG.1) AND SCREW.

HARDWARE	
DESCRIPTION	PCS
BALL HEAD SCREW 8 X 3/4"	4
HOOK	2

PRODUCT IMAGE SHOWN IS FOR ILLUSTRATIVE PURPOSES ONLY, SHOULD NOT BE TAKEN AS REFERENCE POINT



ASSEMBLY INSTRUCTIONS

I-MIX-C007-BN