



① UNSCREW FROM BOTTOM AND TOP OF THE SUPPORT LEAVING THE BOLT IN THE CENTER LOOSEN

② TURN THE SUPPORTS AROUND AND SCREW BACK TO THE FRAME OF THE MIRROR AND TO THE DRESSER