



-ATTENTION-
PLACE THE CENTER SUPPORTS, STARTING WITH THE FIRST SLAT, AND THEN EVERY OTHER SLAT.

INSTRUCTIONS:

- 1.- ATTACH THE RAILS AS SHOWN IN IMAGE "A & B"
- 2.- SCREW THE LEGS TO THE SLAT SUPPORT AND PLACE THEM BETWEEN THE RAILS.
- 3.- FINALLY WHEN BED IS ASSAMLED SCREW THE IRON SUPPORT TO JOIN THE RAILS AS SHOWN IN IMAGE "C"

HARDWARE	
DESCRIPTION	#PCS
SOCKET BUTTON HEAD BOLT 5/16 x 3"	4
SOCKET BUTTON HEAD BOLT 5/16 x 2"	4
WASHER 5/16"	8
IRON SUPPORT	4
FLAT HEAD SCREW 8 x 3/4"	16
LOCK WASHER 5/16"	8
ALLEN KEY 3/16	1

PRODUCT IMAGE SHOWN IS FOR ILLUSTRATIVE PURPOSES ONLY, SHOULD NOT BE TAKEN AS REFERENCE POINT



ASSEMBLY INSTRUCTIONS

I-PLT-C003