



1. WITH SOMEONE HELP'S PLACE THE ISLAND TOP DOWN IN CLEAN AND FLAT SURFACE
2. ALIGN THE BALL CASTER WITH THE HOLES INTO THE LEGS AND INSERT
3. MAKE SURE THAT THE CASTER IS FULLY INSERTED AND PLACE THE ISLAND IN THE RIGH T POSITION.



ASSEMBLING INSTRUCTIONS

I-KSL-E005

DESCRIPTION	#
BALL CASTER	4